

SUPPLEMENTAL DRAWING

EDGE OF SHOULDER

EDGE OF TRAVEL LINE

9. REFER TO THE CURRENT EDITION OF THE AASHTO ROADSIDE DESIGN GUIDE TO DETERMINE LENGTH OF NEED (LON) AND CLEAR ZONE REQUIREMENTS.

B. USE BREAKAWAY SIGNS OR POLES WHEN PLACED IN RECOVERY AREA, MAINTAIN

A. DO NOT PLACE SIGNS OR POLES IN APPROACH AREA.

8. INSTALL REQUIRED MARKING AS PER STD DWG CC 1, TYPE G.

A MINIMUM 10 FOOT CLEARANCE TO SYSTEM.

STD DWG CC 7B